

# GASTEC Instructions for No.123L Xylene Detector Tube

## FOR SAFE OPERATION :

Read this manual and the instruction manual of your Gastec Gas Sampling Pump carefully.

### ⚠ WARNING:

1. Use only Gastec detector tubes in a Gastec Pump.
2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
3. The use of non-Gastec parts or components in Gastec's detector tube and pump system or use of a non-Gastec detector tube with a Gastec pump or use of a Gastec detector tube with a non-Gastec pump may result in property damage, serious bodily injury, and death; voids all warranties; and voids all performance and data accuracy guaranties.

### ⚠ CAUTION : If not observed, injuries to the operator or damage to the product may result.


1. When breaking the tube ends, keep away from eyes.
2. Do not touch the broken glass tubes, pieces and reagent with bare hand(s).
3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sample.

### ⚠ NOTES : For maintaining performance and reliability of the test results.

1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
2. Use this tube within the temperature range of 0 - 40°C (32 - 104°F).
3. Use this tube within the relative humidity range of 0 - 90%.
4. This tube may be interfered with by the coexisting gases. Please refer to the "INTERFERENCES".
5. Shelf life and storage conditions of the tube are marked on the label of the box of tube.

**APPLICATION OF THE TUBE :** Use this tube for the detection of Xylene in air for the industrial areas and environmental atmospheric condition.

**SPECIFICATION :** (As a result of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	2 - 100 ppm	100 - 200 ppm
Number of Pump Strokes	2	1
Correction Factor	1	2
Sampling Time	1 minute per pump stroke	
Detecting Limit	1 ppm (n=2)	
Color Change	White → Brown	
Reaction Principle	Xylene reacts with iodine pentoxide to liberate iodine to produce brown color. $C_8H_{10}(CH_3)_2 + I_2O_5 + H_2SO_4 \rightarrow I_2$	

**Coefficient of Variation : 10%(for 2 to 30 ppm), 5%(for 30 to 100 ppm)**  
**\*\* Shelf Life : Please refer to the Validity Date printed on the box of tube.**  
**\*\* Store the tubes in the dark and cool place.**

## CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE :

**Temperature :** No correction is required.

**Humidity :** No correction is required.

**Pressure :** To correct for pressure, multiply by the tube reading by  

$$\frac{\text{Tube Reading (ppm)} \times 1013 \text{ (hPa)}}{\text{Atmospheric Pressure (hPa)}}$$

## MEASUREMENT PROCEDURE :

1. For leak tight check of the pump insert a fresh sealed detector tube into pump. Follow instructions provided with the pump operating manual.
2. Break tips off a fresh detector tube in the tube tip breaker of the pump.
3. Insert the tube securely into pump inlet with arrow(▶) on the tube pointing toward pump.
4. Make certain pump handle is all the way in. Align guide marks on pump body and handle.
5. Pull handle all the way out until it locks on 1 pump stroke (100ml). Wait 1 minutes and confirm the completion of the sampling. Repeat the above sampling procedure 1 more time
6. For higher than 100 ppm measurement, prepare fresh tube and take 1 pump stroke.
7. Read concentration at the interface of the stained-to-unstained reagent.
8. If correction is needed, multiply the correction factors of pump stroke and pressure.

## INTERFERENCES :

Substance	Interference	Changes color by itself to
Acetylene, Ethylene, Hexane	No effect	No effect
Alcohols, Esters, Ketones	No effect	No effect
Aromatic hydrocarbon	Plus error	Brown

The table of this interference gases primarily expresses the interference of each coexisting gas in the gas concentration range, equivalent to the gas concentration. Therefore, the test result may be given positive result by the other substances not listed in the table. For more information is needed, please contact us or our distributors in your territory.

## DANGEROUS AND HAZARDOUS PROPERTIES :

Threshold Limit Value-Time Weighted Average by ACGIH (2004) : 100 ppm  
 Threshold Limit Value-Short Term Exposure Limit by ACGIH (2004) : 150 ppm  
 Explosive Range : 1.0 - 7.0%

## DISPOSAL INSTRUCTION :

Reagents of the tube do not use toxic substances. When disposing the tube regardless of used or unused, follow the rules and regulations of the local government.

**WARRANTY :** If you have any questions regarding gas detection and quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer : Gastec Corporation  
 6431 Fukaya, Ayase-City, 252-1103, Japan  
<http://www.gastec.co.jp/>  
 Telephone +81-467-79-3910 Facsimile +81-467-79-3979

IM00123LE1  
 Printed in Japan  
 05C1Z